

NOTE:

The Contractor is to check and verify all building and site dimensions
levels and sewer Invert levels at connection points before work starts